


# VC130: User Guide

## In the box:

**SIMPLEFLIX™** | digital video camera


### User Guide



## Locations of controls

### Connecting the tripod

Screw in and secure the tripod (not included) to the bottom of the video camera as shown in the diagram.




- The tripod is great for:
- Eliminating shaking for videos and blurry pictures
  - Macro shooting
  - When using the camera as a webcam

## Video Mode


When you turn on the camera, the default mode is **Video Mode**. Press the [ **MODE** ] button to switch to the **Camera mode**.

1. Make sure that an SD card is inserted into the camera.
2. Turn on the camera, the **Recording Screen** is displayed and the camera is in **Video Mode**.
3. Press the [ **RECORD** ] button to record video (The recording indicator light is lit when recording).
4. To stop recording, press the [ **RECORD** ] button to take a picture.





### Macro shooting

- To film or take pictures of objects up close (6" - 10") such as flowers insects etc., slide the [ **Macro** ] switch to the [ **Macro** ] position.



### General shooting


- For normal video or picture taking, slide the [ **Macro** ] switch back to the [ **Normal** ] position.



## Setting up your camera:

### Battery Installation


1. Open the battery cover by sliding it in the direction of the arrow.
2. Insert 3 alkaline "AAA" size batteries (not included) into the compartment.
3. Replace the battery cover.



### SD card Installation

This camera has no internal memory and requires an **SD / SDHC** card (not included) to record videos or take pictures. The camera can support **SD / SDHC** cards up to **4 GB**. To install the SD card into the camera, follow the steps below:

1. Turn off the camera.
2. Insert the SD card into the card slot (as shown below) until it clicks and locks into place.
3. To remove the card, gently push it in until it pops out.




## Using your camera

### Turning the camera ON/OFF

1. Open the display screen.
2. To turn on the camera, press and **HOLD** the [ **ON** ] button until the display turns on.
3. To turn the camera off, press and **HOLD** the [ **ON** ] button until the display turns off.


### Setting the date/time

1. Turn on the camera.
2. Press the [ **MENU** ] button, and use the [ **MODE** ] button to select [ **ST** ].
3. Use the [ **▼** ] button to scroll down to [ **Date & Time** ] and press the [ **OK** ] button.
4. Adjust the date and time and press the [ **DATE & TIME** ] button to exit the **Menu**.




## Connecting the camera

### Connecting your camera to a TV



- To enjoy and watch or view your videos and pictures on a television, please follow the instructions below:
1. Connect the black plug of the provided A / V Cable to your camera's A / V OUT jack.
  2. Connect the Red and Yellow plugs to your television's matching video (yellow) and audio (red or white) inputs.
  3. Turn on the camera- the display will turn on briefly and shut, while the red LED indicator light will remain lit.
  4. Click on your television's "Input" button until you see the live feed from the camera.
  5. Press the [ **Mode** ] button twice to enter the **Playback Mode**.
  6. Use the [ **←** ] or [ **→** ] button to select a video file, and press the [ **Record** ] button to begin or stop playback. Or select a JPG picture file and press the [ **OK** ] button and select "Slide Show" from the **Playback Mode Settings Screen**. Press the [ **→** ] button and select "Start" to begin a slideshow of all the pictures stored on the camera's SD card.

### Connect your camera to a computer



- To edit or upload and share your videos and pictures, you must first transfer them to your computer. Follow the steps below to connect the camera to your computer, and use the provided Media Impression software to manage, view, edit, and share your videos and pictures.
1. Make sure the camera is turned Off, and that an SD / SDHC card is inserted in the camera before connecting it to your computer.
  2. Insert the smaller end of the USB cable into the camera's USB port.
  3. Connect the larger end of the USB cable into your computer's USB port.
  4. Turn ON the camera.
  5. Look for your camera by clicking on My Computer, it should usually appear as "Removable Disk". Select a file on your camera, and simply move it into your computer (we recommend copying the files into the "My Videos" or "My Pictures" folder of your computer) in the usual way (drag-and-drop, copy-and-paste). Or open the Media Impression software, to easily locate your camera and transfer, view, edit, and upload your video and picture files (See "ArcSoft® Media Impression").
  6. Before disconnecting the camera, click on the "Safely Remove Hardware" icon usually located on the lower right corner of your **Desktop**.

Please do not disconnect the USB cable during loading, as it may cause damage to the camera and the files on the SD card.



## ArcSoft® Media Impression

### Installing



Install the included ArcSoft® Media Impression software before connecting the camera to your computer. With this software you will be able to manage, view, edit, transfer, and easily upload / share your videos and pictures. Follow the instructions below to install the Media Impression software onto your computer.




## Transferring videos and pictures from the camera to your computer




## Viewing videos on your computer



## Viewing pictures on your computer




## Emailing Pictures



## Installing the WebCam Driver

Your Digital Video Camera may also be used as a webcam. This feature is quite useful if you would like to utilize the video function on Skype™ and other similar applications. To use the camera as a webcam you must first install the **WebCam Driver**. Follow the instructions below to install the driver and use the webcam feature.

1. Insert the provided CD into the CD-ROM drive of your computer, and click on "WebCam Driver".
2. Click "Next".
3. Click "Install" and "Finish" when prompted.




## Video Options Menu

- Press the [ **MENU** ] button within any mode and follow the steps below to access the **System Settings Screen**.
1. Use the [ **MODE** ] button to select [ **ST** ].
  2. Use the [ **←** ] / [ **→** ] buttons to select an option, and confirm by pressing the [ **OK** ] button.
  3. Use the [ **←** ] / [ **→** ] buttons to select desired setting and press the [ **OK** ] button to confirm.
  4. Press the [ **MENU** ] button once again to exit the **System Settings Screen**.


## Video Mode Settings

1. Press the [ **MODE** ] button to select **Video Mode**.
2. Press the [ **MENU** ] button to access the **Video Mode Settings Screen**.
3. Use the [ **←** ] / [ **→** ] buttons to select an option, and confirm by pressing the [ **OK** ] button.
4. Press the [ **MENU** ] button once again to exit the **Video Mode Settings Screen**.



## Picture Mode Settings

1. Press the [ **MODE** ] button to select **Picture Mode**.
2. Press the [ **MENU** ] button to access the **Picture Mode Settings Screen**.
3. Use the [ **←** ] / [ **→** ] buttons to select an option, and confirm by pressing the [ **OK** ] button.
4. Press the [ **MENU** ] button once again to exit the **Picture Mode Settings Screen**.



## Playback Mode Settings


1. Press the [ **Playback** ] button to enter the **Playback Mode**.
2. Press the [ **MENU** ] button to access the **Playback Mode Settings Screen**.
3. Use the [ **←** ] / [ **→** ] buttons to select an option, and confirm by pressing the [ **OK** ] button.
4. Press the [ **MENU** ] button once again to exit the **Playback Mode Settings Screen**.



## Using Your camera as a webcam

1. Turn on the camera, and press the [ **OK** ] button.
2. Press the [ **→** ] button and select [ **ST** ] to enter the **System Settings Screen**.
3. Use the [ **←** ] / [ **→** ] buttons to scroll down to [ **PCAM** ] and press the [ **→** ] button.
4. Select "PCAM" and press the [ **OK** ] button.
5. Press the [ **OK** ] button once again to enter the **System Settings Screen**.
6. When you connect the camera, it will be recognized by your computer as a webcam.

When you set the camera to PCAM, you will not be able to access the files on the SD card when connecting the camera to your computer. Make sure to set it back to the default setting by selecting "USB" and then "MSDC" in System Settings.



## Safety Precautions

- Always follow these basic safety precautions when using your camera. This will reduce the risk of product damage and personal injury.
- Do not disassemble, repair or modify the camera by yourself. Refer servicing to qualified personnel.
  - If the LCD display breaks, do not touch the glass or liquid, and contact customer support.
  - The use of a NON-RECOMMENDED accessory may cause fire, electric shock, or injury. For approved accessories, please contact customer support.
  - Keep the camera away from direct sunlight and any direct heat source.
  - Do not expose the camera to rain or moisture.
  - Avoid using the camera in dry environments to avoid static.
  - Never apply heavy impact on the camera, or place it on a magnet.
  - When connecting the camera to a computer or TV, route the cable so that people and pets are not likely to trip over it.
  - Clean only with a dry cloth. Make sure the camera is turned off before cleaning. Do not use a liquid cleanser.
- Important Battery Precautions**
- Use only the type of battery specified in this user manual.
  - In the event that the battery is leaking, do not handle the device with your bare hands. Contact the service center for help since the liquid may remain in the player. If your body or clothes had contact with the battery liquid, wash it off thoroughly with water. Also, if some liquid gets into your eyes, do not rub your eyes but immediately wash them with clean water and consult a doctor.
  - Please help to protect the environment by recycling or disposing of batteries according to federal, state, and local regulations.

## Trouble Shooting

- Camera will not turn on**
- Check that the batteries are properly inserted.
  - Try replacing the batteries.
- The display does not light up, or the message "No Card" is displayed**
- Check that the SD card is properly inserted into the card slot.
- My videos / pictures are fuzzy or poor quality**
- Try adjusting the "Movie Size" and "Frame Rate" from the **Video Mode Settings Screen** or the "Resolution" and "Quality" from the **Picture Mode Settings Screen**. Remember that choosing higher quality settings will take up more space on the memory card.
  - Make sure to keep the camera steady when filming, and be aware of the lighting environment (the more light the better your pictures and videos will turn out).
  - Make sure the [ **Macro** ] switch is set to [ **Macro** ] for general shooting.
  - Avoid using the zoom too much, as it will affect the quality of your video and pictures.
  - Clean the lens of your camera, and make sure it is free of fingerprints (Clean only with a non-abrasive dry cloth and make sure the player is turned off before cleaning).
- My videos are jumpy or shaky**
- Use the included mini tripod.
  - Adjust the video / picture quality to a higher setting.

## Videos do not play on my TV

- Check that you have properly connected the A / V cable to the camera and TV inputs.
  - Make sure that the camera is turned on (the red LED indicator light will be lit, but the display will be off when you connect the A / V cable to the A / V OUT jack of the camera).
  - Most televisions have several inputs, check on the TV or your TV's remote for the button that controls the inputs on your TV. Scroll through the different inputs until you see the live feed from the video camera.
- My computer does not recognize the camera when I connect it to the USB port**
- Check the connection of the USB cable, make sure it is properly connected.
  - If you recently used the webcam feature, you may need to go to the **System Settings Screen** and select "USB" and choose the "MSDC" option.

Still having trouble with your camera? Please call or email customer support:

1-877-768-8483 (Toll Free)  
Monday - Thursday: 9AM - 5PM (EST)  
Friday: 9AM - 3PM (EST)  
or  
via e-mail at [cs@southerntelecom.com](mailto:cs@southerntelecom.com)

## Warranty information

- Limited Warranty**
- In the unlikely event that this product is defective, or does not perform properly, you may within **90** days from your original date of purchase return it to the authorized service center for repair or exchange.
- TO OBTAIN WARRANTY SERVICE:**
- Provide proof of the date of purchase within the package (Dated bill of sale).
  - Prepay all shipping costs to the authorized service center, and remember to insure your return.
  - Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
  - Describe the defect or reason you are returning the product.
- Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.
- The shipping address of the authorized service center is:
- Southern Telecom, Inc.  
ATTN: Returns Department  
14-C 53rd Street  
Brooklyn, NY 11232

- Warranty service not provided**
- This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.
- Limitation of Warranty:**
- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED.
  - NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.
- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.**
- Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

## FCC information

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Do not attempt to repair or modify this equipment.**

**Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

